

18Vx2 Brushless Wet/Dry Dust Extraction Vacuum



The second

BL

inakita

Product Overview



Product Specification Sheet

٠



Max. sealed suction	11kPa		
Max. air volume (m³/min)	2.1m³/min		
Tank capacity	Dry: 15L / Wet: 12L		
Suction power	105W		
Continuous runtime BL1860B x2	40 minutes		
Weight (with battery)	7.8kg		
Voltage	18Vx2 (36V)		

- **Redesigned housing** minimises excess air noise to reduce operation volume
- Large On/Off Switch allows for easy operation
- **Durable Container** Durable plastic container absorbs impacts without denting or warping like metal containers
- **Dual Battery Indicator** Indicates the remaining power in each battery
- Variable Speed Dial easily adjustable suction control for optimum runtime and performance
- 15L Tank Capacity increased tank capacity to minimise down time between disposals
- Removable storage box allows for storing extra batteries and accessories and also doubles as stabiliser
- **Rubber Bumper** eliminates risk of damage to furniture and chairs while moving the vacuum around worksite

Advantages

Performance



18Vx2 Brushless technology provides a High suction for a range of applications

Versatility



Variable suction control for optimum runtime & performance

Convenience



Removable on-board storage & stabilizing leg for pipes, nozzles and batteries

Ergonomic



Large On/Off switch for easy operation

SOur Range

	NEW – DVC155LZX4	DVC150LZ	DVC157LZX2	
Max. sealed suction	11kPa	AC: 24kPa DC: 9kPa	11kPa	
Max. air volume (m³/min)	2.1m³/min	AC: 3.6m³/min DC: 2.1m³/min	2.1m³/min	
Tank capacity	Dry: 15L / Wet: 12L	Dry: 15L / Wet: 12L	15L	
Suction power	105W	AC: 320W DC: 70-25W	105W	
Continuous Runtime (Max) 6.0Ah	40 minutes	36 minutes	40 minutes	
Weight (with battery)	7.9kg	9.6kg	8.5kg	
Voltage	18Vx2(36V)	AC or 18Vx2(36V)	18Vx2(36V)	

Accessories

Standard Accessories		Optional Accessories			
	122512-4	Combination Floor Tool		195557-5	Fleece Filter Bag (5pk)
	192563-1	Straight Aluminium Pipe		140248-3	Cloth Pre-Filter
	192562-3	Bent Aluminum Pipe		195552-5	Foam Damper
	195434-1	38mm Hose x 2.5m		197166-6	HEPA Filter
	410306-2	Crevice Nozzle		195555-9	Wet Filter
	195432-5	Plastic Tub Liner (10pk)		195546-0	Joint Cuff 22-38

195548-6

Front Cuff 24



Frequently Asked Questions

How do I install the HEPA filter?

Remove the 3 x screws attaching the float cage to the bottom of the motor housing. Remove the standard pre-filter and replace with the option cloth pre-filter, foam damper & HEPA filter assembly.

How do I use the vacuum for wet pickup?

Ensure the float cage and float are assembled correctly under the motor housing. Install the plastic tub liner if required and wet filter assembly (optional accessory).